

INSTRUCTIONS

Fixing Caster to Rod:

Place the Robinson Auto-Caster on top of the rod and in front of the reel, as shown in picture.

Note: the release button must be on the same side as the line which comes off the reel.

Clamp the Robinson Auto-Caster to rod with the two releasable cable ties supplied.

Ensure the ties are over the raised square on the Caster jack plates. Fasten the ties as tight as possible, by pulling them tight. Screw down the jack screws to make the cable ties tighter. Cut off the excess ties leaving approx. 100mm surplus so the ties can be reused.

2. Setting up the Release Point:

1. Hold chrome weight and pointer while you loosen the locking nut.
2. Incline the rod to the approximate angle at which you want the line to release.
3. Ensure that the chrome weight is hanging freely.
4. Move the pointer to it's release position (i.e. angle of 90 deg. to the rod).
5. Hold pointer and weight together and tighten the locking nut.
6. Test the unit for correct setting, if not right, reposition the pointer to the correct spot.

3. Casting the Line:

NOTE-IMPORTANT: Make sure the drag is tightened prior to the cast.

1. Hold rod over shoulder in horizontal position (very important) with reel on top and caster underneath.
2. Place line on release button and pull back bale arm.
3. Hold rod with one hand by reel and one hand at end of handle.
4. Cast over your shoulder with the rod moving in a vertical arc.
5. Always cast with a smooth action. Do not jerk the rod as it may result in gear failure. At first, leisurely casts give better results.

Tips:

1. If line moves in a flat trajectory, then move pointer toward the tip of the rod.
2. If line goes in a high trajectory, move pointer towards reel.
3. Maximum recommended casting weight should not exceed 180g (6oz)
4. Practice a few times to ensure you have the right setting, as all rods have a different flex and the best point of release may vary from rod to rod.

HAPPY FISHING !!

